

Solar Wedge Light

Pre - Installation Notes

- Only use a 600mAh, 3.2V, LifePO4 battery with this product (included).
- Install the light in an area that receives ample sunlight daily.


Components



No. 2 Phillips Bit



1/8" Diameter Drill Bit




Solar Wedge Light

Step 1

Prepare the Post With Screws

- 1.1 Cut out and tape the template provided below to the desired location on the post. Drill (2) 1/8in. holes 3/4 inches away from each other on center.
- 1.2 Using a Phillips head bit, install the 2 provided screws into the two pre-drilled holes, leaving a 1/8in. space between the screw head and the post for the solar wedge to rest when installed.



Step 2

Prepare Battery and Install Light

- 2.1 Remove the battery tab from the back of the light by pulling it, allowing contact between the battery and the terminal.
- 2.2 Test the light by covering the solar panel on the slanted face of the wedge, to ensure the light illuminates when introduced to darkness.
- 2.3 Line up the holes on the back of the solar wedge with the screws installed in Step 1.2, and pull down on the wedge to secure it to the post. If it feels too loose or tight, remove the unit, and tighten or loosen screws accordingly.

